




DISP-12-3D.DWG




DISPSA-12-3D.DWG




CA12-12-3D.DWG




CA15-12-3D.DWG




CA18-12-3D.DWG




DISP-35-3D.DWG




DISPSA-35-3D.DWG




CA12-35-3D.DWG




CA15-35-3D.DWG




CA18-35-3D.DWG




OFC-12-3D



OFC-35-3D.DWG




DISPST-35-3D.DWG




RSS-3D.DWG




MSS-3D.DWG




MSSLD-3D.DWG




MRSS-3D.DWG




MRSSLD-3D.DWG




ARSS2-3D.DWG




ARSS-3D.DWG



ARSSLD-3D.DWG




SS33-3D.DWG




DRAWING NAME	DESCRIPTION	DRAWING NAME	DESCRIPTION
DISP-12-3D.DWG	1-2HP disposer	OFC-35-3D.DWG	3-5HP disposer with offset chute
DISPSA-12-3D.DWG	1-2HP disposer/sink adaptor	DISPST-35-3D.DWG	Standard disposer with short top housing
CA12-12-3D.DWG	1-2HP disposer/12" cone package	RSS-3D.DWG	Remote start/stop switch
CA15-12-3D.DWG	1-2HP disposer/15" cone package	MSS-3D.DWG	Manual start/stop disposer control
CA18-12-3D.DWG	1-2HP disposer/18" cone package	MSSLD-3D.DWG	Manual start/stop disposer control w/line disconnect
DISP-35-3D.DWG	3-5HP disposer	MRSS-3D.DWG	Manual reverse start/stop disposer control
DISPSA-35-3D.DWG	3-5HP disposer/sink adaptor	MRSSLD-3D.DWG	Manual reverse start/stop disposer control w/line disconnect
CA12-35-3D.DWG	3-5HP disposer/12" cone package	ARSS2-3D.DWG	Automatic reverse start/stop control panel
CA15-35-3D.DWG	3-5HP disposer/15" cone package	ARSS-3D.DWG	Automatic reverse start/stop control panel
CA18-35-3D.DWG	3-5HP disposer/18" cone package	ARSSLD-3D.DWG	Automatic reverse start/stop control panel w/line disconnect
OFC-12-3D.DWG	1-2HP disposer with offset chute	SS33-3D.DWG	Start/Stop SS33 control panel w/line disconnect


S914-LH-3D.DWG




P914-LH-3D.DWG




S419-LH-3D.DWG





S914-3D.DWG



P914-3D.DWG





S419-3D.DWG




SM-3D.DWG

PSM-3D.DWG




TVL-3D.DWG

TVR-3D.DWG




DRAWING NAME	DESCRIPTION
S914-3D.DWG	S914 collector
P914-3D.DWG	P914 collector
S419-3D.DWG	S419 collector
SM-3D.DWG	Scrapmaster
PSM-3D.DWG	Pot/Pan Scrapmaster
TVL-3D.DWG	Troughveyor left hand
TVR-3D.DWG	Troughveyor right hand



DISP-12-PL.DWG




CA12-12-PL.DWG




CA15-12-PL.DWG



CA18-12-PL.DWG



DISP-35-PL.DWG




CA12-35-PL.DWG




CA15-35-PL.DWG




CA18-35-PL.DWG




DISP-12-EL.DWG




CA12-12-EL.DWG




CA15-12-EL.DWG




CA18-12-EL.DWG




DISP-35-EL.DWG



CA12-35-EL.DWG



CA15-35-EL.DWG



CA18-35-EL.DWG



SA-12-PL.DWG



SA-35-PL.DWG



RSS-PL.DWG



MSS-PL.DWG




MSSLD-PL.DWG




MRSS-PL.DWG



980104-PL.DWG



SA-12-EL.DWG



SA-35-EL.DWG



RSS-EL.DWG



MSS-EL.DWG



MSSLD-EL.DWG




MRSS-EL.DWG




980104-EL.DWG




980104-RS.DWG




OFC-12-PL.DWG



OFC-35-PL.DWG



OFC-12-EL.DWG



OFC-35-EL.DWG




980105-RS.DWG



980105-PL.DWG



980105-EL.DWG



PRINS-EL.DWG



PRINS-PL.DWG




SOLE-PL.DWG



SOLE-REL.DWG



12CC-PL.DWG




15CC-PL.DWG




18CC-PL.DWG


DRAWING NAME	DESCRIPTION	DRAWING NAME	DESCRIPTION
DISP-12-PL.DWG	1-2HP Disposer plan view	MSSLD-EL.DWG	Manual start/stop disposer control w / line disconnect front view
CA12-12-PL.DWG	1-2HP Disposer/12" cone package plan view	MRSS-EL.DWG	Manual reverse start/stop disposer control front view
CA15-12-PL.DWG	1-2HP Disposer/15" cone package plan view	980104-EL.DWG	Bracket for MSS, MSSLD, MRSS, RSS front view
CA18-12-PL.DWG	1-2HP Disposer/18" cone package plan view	980104-RS.DWG	Bracket for MSS, MSSLD, MRSS, RSS right side view
DISP-35-PL.DWG	3-5HP Typical disposer plan view	MRSSLD-PL.DWG	Manual reverse start/stop disposer control w / line disconnect plan view
CA12-35-PL.DWG	3-5HP 12" Disposer/cone package plan view	ARSS-EL.DWG	Automatic reverse start/stop control panel plan view
CA15-35-PL.DWG	3-5HP 15" Disposer/cone package plan view	ARSSLD-PL.DWG	Automatic reverse start/stop control panel w / line disconnect plan view
CA18-35-PL.DWG	3-5HP 18" Disposer/cone package plan view	ARSS2-PL.DWG	Automatic reverse start/stop control panel plan view
DISP-12-EL.DWG	1-2HP Disposer front view	980105-PL.DWG	Bracket for MRSSLD and ARSS plan view
CA12-12-EL.DWG	1-2HP Disposer/12" cone package front view	MRSSLD-EL.DWG	Manual reverse start/stop disposer control w / line disconnect front view
CA15-12-EL.DWG	1-2HP Disposer/15" cone package front view	ARSS-EL.DWG	Automatic reverse start/stop control panel front view
CA18-12-EL.DWG	1-2HP Disposer/18" cone package front view	ARSSLD-EL.DWG	Automatic reverse start/stop control panel w / line disconnect front view
DISP-35-EL.DWG	3-5HP Typical disposer front view	ARSS2-EL.DWG	Automatic reverse start/stop control panel front view
CA12-35-EL.DWG	3-5HP Disposer/12" cone package front view	SS33-PL.DWG	Start/Stop SS33 control panel w / line disconnect plan view
CA15-35-EL.DWG	3-5HP Disposer/15" cone package front view	SS33-EL.DWG	Start/Stop SS33 control panel w / line disconnect front view
CA18-35-EL.DWG	3-5HP Disposer/18" cone package front view	980105-EL.DWG	Bracket for MRSSLD and ARSS front view
SA-12-PL.DWG	1-2HP 6 1/2" sink assembly disposer plan view	980105-RS.DWG	Bracket for MRSSLD and ARSS right side view
SA-12-EL.DWG	1-2HP 6 1/2" sink assembly disposer front view	OFC-12-PL.DWG	1-2HP Disposer with offset chute and 18" cone plan view
SA-35-PL.DWG	3-5HP 6 1/2" sink assembly disposer plan view	OFC-35-PL.DWG	3-5HP Disposer with offset chute and 18" cone plan view
SA-35-EL.DWG	3-5HP 6 1/2" sink assembly disposer front view	OFC-12-EL.DWG	1-2HP Disposer with offset chute and 18" cone front view
RSS-PL.DWG	Remote start/stop switch plan view	OFC-35-EL.DWG	3-5HP Disposer with offset chute and 18" cone front view
MSS-PL.DWG	Manual start/stop disposer control plan view	PRINS-EL.DWG	Pre-rinse front view
MSSLD-PL.DWG	Manual start/stop disposer control w / line disconnect plan view	PRINS-PL.DWG	Pre-rinse plan view
MRSS-PL.DWG	Manual reverse start/stop disposer control plan view	SOLE-PL.DWG	Solenoid plan view
980104-PL.DWG	Bracket for MSS, MSSLD, MRSS, RSS plan view	SOLE-REL.DWG	Solenoid right side elevation
RSS-EL.DWG	Remote start/stop switch front view	12CC-PL.DWG	12" cone bowl cover plan view
MSS-EL.DWG	Manual start/stop disposer control front view	15CC-PL.DWG	15" cone bowl cover plan view
		18CC-PL.DWG	18" cone bowl cover plan view




S914-PL.DWG




S914-PL-LH.DWG




P914-PL.DWG




P914-PL-LH.DWG




S914-EL.DWG




S914-EL-LH.DWG




P914-EL.DWG




P914-EL-LH.DWG




S419-PL.DWG




S419-PL-LH.DWG




RACKGUIDE.DWG




20-RACK.DWG



S419-EL.DWG




S419-EL-LH.DWG



DIFF-PL.DWG




GUSH-PL.DWG




DIFF-EL.DWG




GUSH-EL.DWG




SAL.DWG




SM-PL.DWG




PSM-PL.DWG




TVL-PL.DWG




TVR-PL.DWG




SM-EL.DWG



PSM-EL.DWG



TVL-EL.DWG



TVR-EL.DWG

DRAWING NAME	DESCRIPTION	DRAWING NAME	DESCRIPTION	DRAWING NAME	DESCRIPTION
S914-PL.DWG	S914 collector plan view	S419-PL-LH.DWG	S419 LH collector plan view	SAL.DWG	Simulated operator
S914-PL-LH.DWG	S914 LH collector plan view	S419-EL.DWG	S419 collector front view	SM-PL.DWG	Scrapmaster plan view
P914-PL.DWG	P914 collector plan view	S419-EL-LH.DWG	S419 LH collector front view	PSM-PL.DWG	Pot/Pan Scrapmaster plan view
P914-PL-LH.DWG	P914 LH collector plan view	RACKGUIDE.DWG	Rack guide plan view	TVL-PL.DWG	Troughveyor left hand plan view
S914-EL.DWG	S914 collector front view	20-RACK.DWG	Dish rack plan view	TVR-PL.DWG	Troughveyor right hand plan view
S914-EL-LH.DWG	S914 LH collector front view	DIFF-PL.DWG	Diffuser plan view	SM-EL.DWG	Scrapmaster front view
P914-EL.DWG	P914 collector front view	DIFF-EL.DWG	Diffuser front view	PSM-EL.DWG	Pot/Pan Scrapmaster front view
P914-EL-LH.DWG	P914 LH collector front view	GUSH-PL.DWG	Gusher head plan view	TVL-EL.DWG	Troughveyor left hand front view
S419-PL.DWG	S419 collector plan view	GUSH-EL.DWG	Gusher head front view	TVR-EL.DWG	Troughveyor right hand front view